$$\mathsf{FLR} \le r_{y} \left(1800 + 1500\beta_{m}\right) \left(\frac{b_{f}}{b_{w}}\right) \left(\frac{250}{f_{y}}\right)$$

where FLR = maximum segment length for full lateral restraint

$$r_y = \sqrt{\left(\frac{I_y}{A_g}\right)}$$
 (see Tables 3.1-3 to 3.1-4)

The FLR values listed in the (A) series tables of Tables 5.2-1 to 5.2-2 are calculated using $\beta_m = -1.0$ which is the most conservative case. However, $\beta_m = -0.8$ may be used for segments with transverse loads (as in the case of Tables 5.1-3 to 5.1-4) or β_m may be taken as the ratio of the smaller to larger end moments in the length (*L*) for segments without transverse loads (positive when the segment is bent in reverse curvature).

5.2.2.3 Design Torsional Moment Section Capacity

The design torsional moment section capacity (ϕM_z) listed in the 5.2 Table series is determined in accordance with (a) and (b) as noted below.

(a) Although AS 4100 makes no provision for the design of members subject to torsion it is nevertheless considered appropriate to provide torsional capacities for hollow sections in the Tables. Hollow sections perform particularly well in torsion and their behaviour under torsional loading is readily analysed by simple procedures. An explanation of torsional effects is provided in Refs. [5.1, 5.2].

The general theory of torsion established by Saint-Venant is based on uniform torsion. The theory assumes that all cross-sections rotate as a body around the centre of rotation.

When the torsional moment that is applied is non-uniform, such as when the torsional load is applied midspan between rigid supports or when the free warping of the section is restricted, then the torsional load is shared between uniform and non-uniform torsion or warping. However, in the case of hollow sections, the contribution of non-uniform torsion is negligible and sections can be treated as subject to uniform torsion without any significant loss of precision.

(b) For hollow sections, torsional actions can be considered using the following formulae:

$$M_{\rm Z}^{\star} \leq \phi M_{\rm Z}$$

$$\phi M_z = \phi 0.6 f_y C$$

where

 M_z^* = design torsional moment

 ϕ = 0.9 (based on shearing loads and Table 3.4 of AS 4100)

 ϕM_z = design torsional section moment capacity

 f_y = yield stress used in design

C = torsional section modulus (see 3.1 Table series)

The angle of twist per unit length θ (in radians) can be determined from the following formula:

$$=\frac{M_{z}^{2}}{GJ}$$

where

θ

J

G = shear modulus of elasticity, 80 x 10³ MPa

= torsional section constant (see 3.1 Table series).

The method for determining the constants C and J is detailed in Section 3.2.1.1.



design capacity tables for structural steel



Volume 2: Hollow Sections second edition

- CHS Grade C250/C350 (to AS 1163)
- RHS Grade C350/C450 (to AS 1163)
- SHS Grade C350/C450 (to AS 1163)

- Foreword (iv)
- Acknowledgements (iv)
 - Preface (v)
 - Notation (vi)

PART ONE Introduction 1-1

> PART TWO Materials 2-1

PART THREE Section Properties 3-1

PART FOUR Methods of Structural Analysis 4-1

PART FIVE Members Subject to Bending 5-1

PART SIX Members Subject to Axial Compression 6-1

PART SEVEN Members subject to Axial Tension 7-1

PART EIGHT Members subject to Combined Actions 8-1



design capacity tables for structural steel

Volume 2: Hollow Sections

second edition

TABLE OF CONTENTS



CONNECTION

PART 5 MEMBERS SUBJECT TO BENDING

5.1	Maximum Design Loads for Beams with Full Lateral Restraint5	-3
5.1.1	Strength Limit State Design5	-3
5.1.1.1	W [*] _{L1} based on Design Moment Capacity5	
5.1.1.2	W_{L2}^* based on Design Shear Capacity	-4
5.1.2	Serviceability Limit State Design5	
5.1.2.1	$W_{\rm S}^{*}$ based on a Deflection Limit of <i>L</i> /250	
5.1.2.2	W [*] _{YL} based on First Yield Load5	-5
5.1.3	Full Lateral Restraint5	-5
5.1.4	Additional Design Checks5	-5
5.1.5	Other Load Conditions5	-5
5.1.6	Examples5	-7
5.2	Design Section Moment and Web Capacities5	-9
5.2.1	General5	-9
5.2.2	Method5	-9
5.2.2.1	Design Section Moment Capacity5	-9
5.2.2.2	Segment Length for Full Lateral Restraint (FLR)5	
5.2.2.3	Design Torsional Moment Section Capacity	
5.2.2.4	Design Shear Capacity of a Web	
5.2.2.5 5.2.3	Design Web Bearing Capacities	
5.2.4	Shear and Bending Interaction	
5.2.4.1 5.2.4.2	Method	
5.2.5	Bending and Bearing Interaction	
5.2.5.1	Method	
5.2.5.2	Example	
5.3	Design Moment Capacities for Members Without Full	
	Lateral Restraint5-	16
5.3.1	General5-	16
5.3.2	Design Member Moment Capacity5-	17
5.3.3	Beam Effective Length5-	17
5.3.4	Other Loading and Restraint Conditions	17
5.3.5	Segment Length for Full Lateral Restraint5-	18
5.3.6	Examples5-	18



5.4	Calculation of Beam Deflections5	5-20
5.5	References	5-20
	TABLES	
TABLES 5.1-1 to	5.1-6	
	Maximum Design Loads for Beams with Full Lateral Restraint	j-22
TABLES 5.2-1 to	5.2-4	
	Design Section Moment and Web Capacities (RHS & SHS only)5 (A) Tables – Bending about x-axis for RHS (B) Tables – Bending about y-axis for RHS	j-56
TABLES 5.3-1 to	5.3-2	
	Design Moment Capacities for Members without Full Lateral Restraint (RHS only)	5-74

NOTE: SEE SECTION 2.1 FOR THE SPECIFIC MATERAL STANDARD (AS 1163) REFERRED TO BY THE SECTION TYPE AND STEEL GRADE IN THESE TABLES